


## **2018 Specifications** for PC's Running SafeDispatch

## **Application Server PC**

In order to effectively install and run the SafeDispatch Application components including the Database, Application Server, Gateway and Admin Module within the application, a specific PC must be dedicated to the application alone. The *Application* Server PC would also be the PC that will have your control station MOTOTRBO® radios connected as well.

Requirement	Minimum	Recommended
Operating System (s)	Windows 10 Professional 64-bit,	Windows 10 Professional 64-
	English or Windows Server 2016	bit, English or Windows Server
		2016
Processors	Intel® Core i5-5250U Processor	Intel® Core i7-7820HK or
		Intel® Core i9 7900x processor
Memory	8GB DDR4 at 2400MHz	32GB Quad Channel DDR4 at
		2666MHz
Boot Hard Drives	500 GB m.2 PCIe SSD	1TB m.2 PCIe SSD
Graphics Cards	NVIDIA® GeForce® GTX 1050 OC	NVIDIA® GeForce® GTX 1080
	with 4GB GDDR5	OC with 8GB GDDR5
Ports	4 free USB, RJ 45 (Gigabit	4 free USB, RJ 45 (Gigabit
	Ethernet)	Ethernet)

These specifications can be found at online. SafeMobile **DOES NOT** provide PC's to Dealers. Should you choose another PC manufacturer, please be sure the specifications are adequate and comparable to those noted above.



## **2018 Specifications** for PC's Running SafeDispatch

## **Dispatcher PC**

In order to effectively install and run the SafeDispatch Application suites including the maps and other modules such as GPS, History, Texting, etc. a specific PC must be dedicated to the application alone.

Requirement	Minimum	Recommended
Operating System (s)	Windows 10 Professional 64-bit,	Windows 10 Professional 64-
	English	bit, English or Windows
		Server 2016
Processors	Intel® Core i3-6100 Processor	Intel® Core i5-5250U
		Processor
Memory	4GB DDR4 at 2400MHz	8GB DDR4 at 2400MHz
Boot Hard Drives	250 GB m.2 PCIe SSD	1TB m.2 PCIe SSD
Graphics Cards	Integrated Graphic Card	NVIDIA® GeForce® GTX 1050
		OC with 4GB GDDR5
Ports	4 free USB, RJ 45 (Gigabit	4 free USB, RJ 45 (Gigabit
	Ethernet)	Ethernet)

These specifications can be found at online. SafeMobile **DOES NOT** provide PC's to Dealers. Should you choose another PC manufacturer, please be sure the specifications are adequate and comparable to those noted above.